



Multipurpose Bag for Camping

Design & work: Kokka Fabric

Size: approx. 30cm (l)
approx. 48cm (w)
approx. 14cm (d)
(excludes handles)



Materials

- Outer Fabric: approx. 110cm wide x 70cm
- Lining Fabric: approx. 110cm wide x 60cm
- Fusible Interfacing (heavy weight): approx. 110cm wide x 60cm
- Tape: approx. 30mm wide x 120cm

Fabric shown for this sample: YPA-69000-1C

Pattern

Unit: cm [] : denotes seam allowance
When cutting the fabric, add 1cm seam allowance unless specified otherwise.



※Adhere fusible interfacing on the back of the outer bag fabric and outer bottom fabric.

Multipurpose Bag for Camping


have fun with KOKKA fabric! produced by **KOKKA**

kokka-fabric.com


The craft projects and works featured in kokka-fabric.com are strictly for personal use and enjoyment.
Please refrain from selling handmade items using the same exact design (including the pieces
made in different fabrics) featured in kokka-fabric.com.

Instructions FrS - (FrS), RvS (RvS)


1. Make the pocket and attach it to the outer bag fabric




Attach it to outer bag fabric.




Fold the gusset and baste.




2. With the front sides facing each other, sew together the bag fabrics at the sides




3. With the front sides facing each other, sew together the bag fabric and bottom fabric



4. With the front sides facing each other, sew together bag fabrics at the top opening



5. Turn it inside out and apply stitches around the top opening



6. Attach the tape to the bag fabric to finish

