



Mini Bag

Design & work: Mioko Sugino

Size: 16cm (l) 24cm (w) 6cm (gusset)

Materials

- Fabric(Handle, Pocket): 110cm wide x 40cm
- Fabric(Panel, Gusset): 110cm wide x 40cm
- Plasnap Snap Button: 1.3cm diameter x One pair

Fabric shown for this sample: EKX-1710-3A

have fun with KOKKA fabric! produced by KOKKA

kokka-fabric.com

The craft projects and works featured in kokka-fabric.com are strictly for personal use and enjoyment. Please refrain from selling handmade items using the same exact design (including the pieces made in different fabrics) featured in kokka-fabric.com.

Instructions Front Side - (FrS), Reverse Side (RvS)

1. Make the handle

With the front sides facing outside, fold in four and sew.

• Make two pieces.

2. Make the outer pocket

① With the front sides facing each other, sew two pieces together at the pocket opening with the handle in between.

④ Turn it inside out. Apply stitches at the pocket opening.

• Make two pieces.

3. Make the inner pocket

With the front sides facing outside, fold in half and sew the pocket opening side.

• Make two pieces.

4. Make the panel outer fabric

① Baste the outer pocket with zigzag stitches.

5. Make the panel lining fabric

① Make the front panel.

② Sew the center partition. • Make two pieces.

② Make the back panel.

③ Baste the inner pocket with zigzag stitches. Repeat the same process as in ②①-②. ③ Sew the partition.

6. Make the gusset

• Make two pieces.

7. Make the outer bag

① With the front sides facing each other, sew together the panel and gusset and press the seam open.

8. Make the lining bag

Repeat the same process as in ⑦.

① Fold the top opening of the outer bag and lining bag by 1cm. With the front sides facing outside, sew together (avoiding the handle).

9. Finish the bag

② Attach the Plasnap. (凸 on the front, 凹 on the back)

Pattern and Cutting Layout

Unit: cm All raw edge

