



Clutch Bag

Design & work: Kokka Fabric

Size: Maximum width - about 43cm, Top opening - about 31cm Height - about 19cm, Gusset - about 12cm

Materials

☐ Outer fabric: 110cm widex30cm ☐ Lining fabric: 110cm widex30cm


☐ Fusible interfacing (heavy weight): 110cm widex30cm

□ Zipper: 30cm x One piece

Fabric shown for this sample: P49700-700B

Pattern

Unit: cm []: Seam allowance. Add 1cm seam allowance unless specified otherwise.




* Adhere fusible interfacing on the back of the outer fabric.


Instructions

1. Attach the zipper

① With the front sides facing each other, put the outer and lining fabrics with the zipper in-between and sew together.



② Repeat the process and sew together the other outer fabric and lining fabric.



2. Sew together the outer and lining fabrics

Opening for turning

about 16cm

With the front sides facing each other, sew together the outer fabric and lining Sew at 1cm. fabric respectively at the sides and bottom. Outer fabric 1) Sew the bottom (Leave an opening for turning on the lining fabric.) (front side) Outer fabric (reverse side) Leave for 1cm. Leave for 1cm. Sew at 1cm. ② Leave the zipper open Lining fabric and sew the side. Press down the seam (front side) to the outer fabric side. Leave for 1cm. Lining fabric Leave for 1cm. (reverse side)


3. Sew the gussets

kokka-fabric.

made in different fabrics) featured in kokka-fabric.com.


The craft projects and works featured in kokka-fabric.com are strictly for personal use and enjoyment. Please refrain from selling handmade items using the same exact design (including the pieces

Sew the gussets on both outer and lining fabrics.



4. Turn it inside out and close the opening for turning

Turn it inside out and close the opening using blind stitches.



Align the shape and finish!