



Adjustable Height Tote Bag

Design & work: Yui Tamaki

Size (when zipper is opened):

- 30cm (l)
- 30cm (w-at the opening)
- 20cm (bottom)
- 10cm (gusset)

Materials

- Fabric (Outer Fabric-Top and Bottom, Lining Fabric, Handle, Tag): 110cm wide x 80cm
- Fabric (Outer Fabric-Middle): 35cm x 30cm
- Open Bottom Zipper: 60cm x One piece


Fabric shown for this sample:

(Outer Fabric-Top and Bottom, Lining Fabric, Handle, Tag) YK-11040-2E

(Outer Fabric-Middle) YK-11040-1E

Pattern and Cutting Layout

Unit: cm Add 1cm seam allowance unless specified otherwise.



have fun with KOKKA fabric! produced by KOKKA


kokka-fabric.com

The craft projects and works featured in kokka-fabric.com are strictly for personal use and enjoyment. Please refrain from selling handmade items using the same exact design (including the pieces made in different fabrics) featured in kokka-fabric.com.

Instructions Front Side - (FrS), Reverse Side (RvS)



1. Make the handl

① With the front sides facing each other, fold in half and sew the long end.



2. Make the outer bag

① With the front sides facing each other, sew together the outer top fabric and middle fabric.
② With the front sides facing each other, sew together the outer middle fabric and bottom fabric.
③ Make another piece of ②.
④ Fold the seam of the tag. Sew it onto the outer face.




3. Make the lining bag






Using the lining fabric, repeat the process as in ② - ⑤ ⑦ ⑨ (leave a 10cm opening for turning at the bottom) and ⑩.

4. Finish the bag

① With the front sides facing each other, sew together the outer and lining bags at the top opening.



② Turn it inside out and close the opening for turning. Apply stitches at 0.5cm from the top around the opening.



⑩ Make the gusset.
• Repeat the same process on the other side.

